



Technical Inspection form

DRIVER NAME(S) _____

MAKE/MODEL _____ YEAR _____ COLOR _____ S/N _____

ITEM	COMMENTS	OWNER	MECHANIC
BRAKE LIGHT	Check with ignition on.		
BRAKE PEDAL	Check for adequate height off floor. Pump twice & hold for firm pedal.		
BRAKE FLUID	Check fluid level. Check for leaks. Change if more than 12 months old.		
BRAKE PADS	If in doubt, remove wheel and check.		
BRAKE LINES	Inspect/feel for rub spots, cracks, soft spots, excessive stiffness. Check for any leaks.		
TIRES	Check tread depth (1/16th min.). Check for cracks. Speed rating H or better for White VR or better rating for Blue/Red.		
WHEELS	Check lug nut torque. Check for loose or broken spokes with pen. Check for cracks. If newly painted, scrape off paint under lug bolts.		
SUSPENSION	Push/Pull top of tire to shake car front & rear. Check for excessive bearing, axle, or suspension play. Check for play in steering.		
FUEL LINES	Look/smell for leaks, drips, cracks, dampness, wet fuel stains. Feel cloth covered for dampness. Check near carbs, fuel pump, filler neck, tanks & crossover lines.		
COOLANT HOSES	Look for leaks, bulges, squeeze for soft spots at engine & radiator. Check all hose clamps as secure. Expansion tank not too full. Does system need air bleeding?		
BELTS	Look for splits/cracks. Then check for tension. Check for interference.		
OIL LEAKS	Look for large oil leaks, especially near exhaust.		
SEAT BELTS	Check for solid anchor points, no badly frayed belts, metal to metal fasteners. Secure seat mounts & slide latch.		
BATTERY	Check for secure mounting. Taping terminals to prevent shorting is recommended for street cars.		
FIRE EXTINGUISHER	Firmly mounted in easy reach of driver. FULLY charged. <i>(Required for Blue/Red only)</i>		

I have inspected this vehicle, and find it to be in safe, operating condition for this event.

MECHANIC'S SIGNATURE: _____

MECHANIC'S NAME (PRINT): _____

DEALER/SERVICE CENTRE: _____

DATE OF INSPECTION: _____

<p>STAMP</p>

*Technical inspection is not a guarantee of fitness for any particular purpose.
Vehicle condition remains entirely the responsibility of the owner and the driver*